



BUILDING MATERIALS + SALVAGE

Rocker Shelf

Buy Now: Salvaged Architectural Fir Piece, Custom Made Brackets
Also Need: Saw, Sander, Sand Paper, Fasteners, Finishing Oil or Varnish

Step 1: Trim Ends so that they are even

Step 2: Sand fir all over at 120, 220 and then again at 320

Step 3: Hand Sand to bevel edges to liking

Step 4: Finish fir with oil or varnish of choice

Step 5: Locate where you want the center of your shelf to be on wall

Step 6: Measure 16 inches out from center in both directions. Mount brackets to wall at each mark, using top hole only. Make sure to account for height of fir piece for placement

Step 7: Place shelf in brackets temporarily. Make sure it is centered and even. Scribe angle of bracket on wall. Remove fir piece. Mount second hole of bracket to wall at the angle

Step 8: Place shelf in brackets and attache to brackets